

MATERIAL DATA SHEET

DESCRIPTION

TREADMASTER CONTACT ADHESIVE FOR USE WITH ANTI-SLIP DECK COVERING



ORDER CODE

TM 230

PARAMETER	VALUE
SOLIDS	28±1%
SPECIFIC GRAVITY	0.88
FLASH POINT	-30°C
COVERAGE	3.5M ² /L
TIN SIZE	1L
OPEN TIME	7MINS (MIN) 40MINS (MAX)
HEAT RESISTANCE	EXCELLENT

APPLICATION

SOLVENT BASED CONTACT ADHESIVE WITH GOOD HEAT AND WATER RESISTANCE. IDEALLY SUITED FOR USE WITH TREADMASTER ORIGINAL. THE ADHESIVE REMAINS FLEXIBLE ALLOWING MOVEMENT OF FLOORS AND DECKS. WITH THE ABILITY TO WALK ON IMMEDIATELY AFTER FITTING, TREADMASTER MARINE CONTACT ADHESIVE CAN BE USED WITH FIBREGLASS, WOOD, ALUMINIUM AND STEEL DECKS.

SURFACES MUST BE CLEAN, DRY AND FREE FROM OIL AND GREASE. EXISTING PAINT, VARNISH, WAXES, POLISHES ETC MUST BE REMOVED. SURFACES MAY BE CLEANED USING OUR ISOPROPYL WIPES CW3936

WHEN BONDING TREADMASTER TO ALUMINIUM SURFACES, THE ALUMINIUM SHOULD BE ABRADED WITH FINE ABRASIVE PAPER IMMEDIATELY BEFORE USING MARINE CONTACT ADHESIVE.

DO NOT USE AT TEMPERATURES BELOW 10°C. STIR THOROUGHLY BEFORE USE.

This information and our technical advice, whether verbal, in writing or by way of trials, is given in good faith but without warranty. This also applies where proprietary rights are involved. Our advice does not release you from the obligations to check its validity and to test our products as to their suitability for the intended use. The storage, application and use of our products are beyond our control and, therefore, entirely your own responsibility. Our products are sold in accordance with our General Conditions of Sale. The information contained within this data sheet is subject to change without notice.

THE ADHESIVE CAN BE APPLIED BY BRUSH OR ROLLER.
CUT THE TREADMASTER TO SHAPE AND MASK OFF THE DECK AREA TO EXACTLY FIT THE TREADMASTER PANELS.

A SPACE OF 20 - 50MM SHOULD BE LEFT BETWEEN ADJACENT PANELS.
APPLY A THIN, EVEN COAT OF ADHESIVE TO BOTH SURFACES, WORKING FAIRLY QUICKLY AND TAKING CARE TO KEEP ADHESIVE AWAY FROM THE FACE SIDE OF THE TREADMASTER. ALLOW TO DRY UNTIL THE ADHESIVE IS TOUCH DRY (10 – 40 MINUTES DEPENDING ON TEMPERATURE).

THEN ALIGN THE PANEL CAREFULLY AND BRING INTO CONTACT WITH THE DECK SURFACE. APPLY FIRM PRESSURE, PREFERABLY WITH A SMALL HAND ROLLER OVER THE WHOLE PANEL. WORK FROM THE CENTRE TO THE EDGE TO AVOID AIR ENTRAPMENT.